Premier TotalProtect for HigherEd Tech





EXTEND THE LIFE OF YOUR NEW & EXISTING DEVICES WITHOUT BREAKING YOUR BUDGET

Purpose-Built for HigherEd

During the pandemic, many school districts implemented 1:1 device programs—backed by temporary funding. Covid funding is gone, but the need for reliable student technology hasn't changed. With tighter budgets and limited options for large-scale replacements, extending the life of your existing devices is more important than ever.

What We Offer:

- Extended Warranties for New and Existing Chromebooks, Laptops and Tablets
- Coverage Options from 1 to 4 years
- Unlimited Claims for Schools

Why This Matters Now:

- Maximize your current investment—don't replace devices, protect them
- Avoid unplanned repair costs and reduce downtime

- Accidental Damage Protection (drops, spills, & cracked screens)
- \$0 Deductibles
- Optional Lost/Stolen Coverage Available
- Stretch your tech budget during periods of financial shortfall
- Maintain device equity without cutting corners on student access

Flexible & Scalable

Whether you're protecting a few hundred devices or managing a district-wide fleet, Premier Wireless provides custom warranty solutions tailored to your needs, timeline, and budget. You choose the coverage duration—1, 2, 3, or 4 years—based on the remaining life and usage of your devices.

Let's Protect Your Technology Investment

Contact us for a quote or to learn how easy it is to add extended warranties to your existing Chromebook fleet.

Protect your technology. Sustain your services. Empower your community.



For more information, contact:

- www.premierwireless.com
- **(281)** 667-0404
- sales@pwbts.net













PLAN COVERAGE OPTIONS

	ADH* Only	EXT** Only	ADH + EXT	ADH + EXT + Theft	ADH + EXT + Theft + Loss
Broken glass screen			•	Ø	⊘
Broken LED/LCD displays	Ø		Ø	Ø	⊘
Electrical failures caused by accidental damage	⊘		⊘	•	⊘
Liquid or water damages or failures from accidental spills	Ø		Ø	Ø	•
Liquid or water damages or failures from accidental submersions	⊘		⊘	Ø	⊘
Power surge		Ø	Ø	Ø	⊘
Display/touchscreen failure		•	•		
Charger and/or other ports failures		•	•	•	
Speaker failures		Ø	Ø	⊘	⊘
Camera failures		Ø	Ø	Ø	⊘
Battery failures		Ø	Ø	⊘	⊘
Other internal components failures		•	•		⊘
Theft				Ø	⊘
Loss					Ø

^{*} ADH - Accidental Damage from Handling

^{**} EXT - Extended Warranty